


A - M6x25mm X3 **B - M8x12mm X14** **C - M5x10mm X4** **D - M8 washer X18** **E - M8 nut X4**





Assembly Kit

F - M4x20mm X4 **H - M6x20mm X4** **J - M5 washer X4** **K - M6 washer X4** **M - M4x5mm X4** **O - M6x6mm X4**
G - M5x20mm X4 **I - M8x20mm X4** **L - M8 washer X4** **N - M5x5mm X4** **P - M8x6mm X4**





TV Fixing Kit


Also required: Pozi screwdriver




5a




5b




6a




6a




6b




7a



7b



7c



8

