


# Silent Angel

## Expander E1




### Package Contents



- E1 x1
- Power Cord x1
- Power Adaptor x1
- USB Cable x1 ( one end is USB3.0 Type-B, another is USB3.0 Type-A )
- User Manual x1
- Warranty Card x1

# Connection Diagram



## Front Panel




### ① Power Status Indicator

When power is on and in good condition, it shows Blue Light.

When functioning as a storage to read or write, it shows Two-color Light( Blue static; Red flashes )

When no power signal, it shows no light

## Rear Panel



### ② DC Input

DC 12V power input ( can connect to 12VDC power adaptor, Silent Angel F2 or other 12VDC linear power supply )

### ③ Power Switch

Control power on/off

### ④ USB Port

USB3.0 Type-B female connector ( can connect to Silent Angel Z1, music server, Silent Angel M1/M1T or music streamer )

## Silent Angel

© 2021 Thunder Data Co. Ltd. All rights reserved.

support@thunder-data.com

<http://www.silent-angel-audio.com/>